



# LUCAS

*Quality*

**EQUIPMENT & SPARE PARTS**

**FOR CARS AND  
COMMERCIAL VEHICLES**

**1945 — 1960**

**• BIRMINGHAM • ENGLAND**



ALFA-ROMEO 'Giulietta Sprint Veloce' (750E), 'Giulietta Spyder Veloce' (750F) and 'Giulietta Sprint Speciale' 1958-60

Unit	Year	Part No.	Unit	Year	Part No.	Unit	Year	Part No.
Circuit breaker, windshield wiper (except 'Sprint Speciale')	1958-60	78316A	Relays, headlamp flasher and horn	1958-60	*33116B	Windshield wipers—cont'd		
LAMPS			SWITCHES			Crosshead and rack Assy. Cut to 29 1/2"	1958-60	743221
Head			Dipper	1958-60	31284A	Outer casing	1958-60	744327
With rim (U.S.A.)	1959-60	51504A	Lighting	1958-60	31158F	Motor to wheelbox	1958-60	744217
Less rim (U.S.A.)	1959-60	51928E	Windshield wipers			Wheelbox to wheelbox	1958-60	740746
Less rim and adaptor (U.S.A.)	1959-60	58176A	Motor	1958-59	75213D	End tube	1958-60	740715
			Wheelbox	1958-60	75213F	Ferrule, casing retaining	1958-60	743257
					72699B	Arm	1958-60	737897
						Blade	1958-60	

ALFA-ROMEO '2000' Model 1958-60: '2000' Spyder 1959-60

Relays, headlamp flasher and horn	1958-60	*33116B	Windshield wipers ('Spyder')			Windshield wipers—cont'd		
SWITCHES			Motor	1958-60	75335A/B	Ferrule, casing retaining	1958-60	740715
Dipper	1958-60	31284A	Wheelbox	1958-60	72705A	Arm, left hand	1958	*744142
Foglamp	1959-60	*31515A	Crosshead and rack Assy. Cut to 29 1/2"	1958-60	744256	" " ("Spyder")	1959-60	54711211
Lighting	1958-60	31158F	Crosshead and rack Assy. ("Spyder") Cut to 32 1/2"	1959-60	744254	" " right hand	1958	748853
Panel rheostat	1959-60	78336A	Outer casing			" " ("Spyder")	1959-60	54711201
Windshield wiper	1958	*31427D	Motor to wheelbox	1958-60	5471017A	" " " ("Spyder")	1959-60	54711202
"	1959-60	31957A	ditto ("Spyder")	1959-60	54710414A	Blade	1958-59	*737907
			Wheelbox to wheelbox	1959-60	54710173		1960	54711283
			End tube	1958-60	740746			

ALLARD 16 h.p. 1947-49

Ammeter	1947-49	*369001	SWITCHES—continued			Windshield wipers—cont'd		
Battery	1947-49	SLG13E	Ignition and lighting	1947-49	*34026D	Inner cable rack		
Coil, ignition	1947-49	*45039A	Panel	1947-49	31201B	Sports Saloon	1947-48	736024
Control box	1947-49	*37076A	Knob	1947-48	*314683	Outer casing		
Distributor	1947-49	40223A	"	1949	*314664	Motor to control box		
Fuse box	1947-49	*37137A	Petrol	1947-49	31201B	Sports Saloon	1947-48	*739907
Generator	1947-49	238498	Knob		*314421	Motor to wheelbox	1949	*739907
Horn			Solenoid, starting motor	1947-49	*760080	Sports Saloon		
Low note	1947-49	*69021A	Solenoid operating	1947-49	*31071A	Open Sports and Coupé	1949	*739907
High note	1947-49	*69022A	Windshield wiper	1948-49	31201B	4", nearside wheelbox	1947-48	740032
LAMPS			Knob		*314691	Sports Saloon	1949	*739956
Boot	1947-49	56035E	Trafficators	1947-48	*54014D	Open Sports and Coupé	1949	*739956
Head, Home				1949	*54023D	Wheelbox to wheelbox	1949	*739956
R.H.D., dip left (L.H.)	1947-48	*50165A	Windshield wipers			Sports Saloon	1947-48	740032
" non-dip (R.H.)	1947-48	*50166A	Motor			Open Sports and Coupé	1949	*739956
" dip left (L.H.)			Sports Saloon	1947-48	*75055K	Late	1949	*739956
" non-dip (R.H.)	1948-49	50793B	Open Sports and Coupé	1947-49	*75063K	3", offside wheelbox	1947-49	740031
" Later			ditto	1949	*75063K	Control box to wheelbox (Sports Saloon)	1947-48	740246
" non-dip (R.H.)	1948-49	*50362F	Coupling bar	1947-49	727293	Guide tube	1947-48	735895
Head, Export			Open Sports and Coupé	1947-49	731721	Sports Saloon	1947-49	734458
R.H.D., dip left (L.H. and R.H.)	1948-49	*50793B	Bearing, passenger side	1947-49	72547A	Arm		
Head, Export U.S.A.	1949	50811A	Open Sports and Coupé	1947-48	72592A/K	Sports Saloon	1947-48	*735098
Number plate illumination (4 seater)	1947-49	53093E	Control box	1947-48	72567A	Open Sports and Coupé	1949	*737517
(2 seater)	1947-49	*53034A	Sports Saloon	1947-48	72568A	(L.H.)	1947-49	*735135
Reverse, tail and number plate (4 seater)	1947-49	53032B	Wheelbox	1949	72592A/K	(R.H.)	1947-49	735132
Side (U.S.A.)	1947-49	*52162A	Sports Saloon	1947-48	72592A/K	" " Later	1949	737517
Stop tail and number plate (4 seater)	1947-49	*53027B	ditto (with switch)	1949	72567A	Blade		
Starting motor	1947-49	*270557	ditto (less switch)	1949	72568A	Sports Saloon	1947-48	727707
Steering column control	1947-49	32732B/D	Open Sports and Coupé	1949	72592A/K	Sports Saloon	1949	*737516
SWITCHES			Late			Open Sports and Coupé	1947-49	727707
Foglamp	1947-49	31201B	Crosshead and rack Assy. Cut to 34 1/2"	1947-48	738499	ditto	1949	736414
Knob		*314665	Cut to 47 1/2" Late	1949	736177			
			Open Sports and Coupé					
			Cut to 47 1/2" Late	1949	738499			

ALLARD 'J', 'J2' and 'J2X' Models 1949-55

Ammeter	1949-51	*369001	Junction box	1951-55	78266B	LAMPS—continued		
"	1952-55	*36117A	"	1953-55	78265B	Head, Export U.S.A.	1949-51	50897B
Battery	1949-52	SLG13E				"	1952-55	50877B
" Later	1952-55	GT11A	LAMPS			Head, Export Europe (not France)	1951	*B50869D
Coil, ignition	1949-55	*45012A/D	Fog	1951-55	*55055B/D	ditto	1951-55	50986A
ditto (Cadillac eng.)	1951-55	*45039A	Head, Home			ditto (flush fitting)	1955	51535A
Control box	1949-51	*37076A	R.H.D., dip left (L.H.)	1949-51	*50869D	Head, Export France	1951-55	50987A
"	1952-55	*37139D	" non-dip (R.H.)	1949-51	*50870D	Number plate illumination	1949-55	53093E
Distributor	1949-55	40068A/F	Head, Home (alternative)			Side	1949-52	52160A
ditto (Cadillac eng.)	1951-55	40253A	R.H.D., dip left	1950	50825A	"	1953-55	52139B
Fuse box	1949-51	*37137A	ditto	1952-54	51331A	" (U.S.A.)	1949-55	*52162B/D
"	1952-55	033239	ditto (flush fitting)	1955	51336A	" (special orders)	1953-55	*52143A
Generator	1949-50	238498	Head, Export			Stop tail	1949-55	53178B/D
"	1950-52	22443A	R.H.D., dip left (L.H. and R.H.)	1951	*50869D	" (U.S.A.)	1949-50	53173B
"	1952-53	*22465A	Head, Home and Export			Stop tail and reverse (U.S.A.)	1950-55	53184B
"	1953-55	22478A	R.H.D., dip left (L.H. and R.H.)	1951-55	*50985A	Starting motor	1949-50	*270557
Horn			Head, Export			ditto	1951-55	26060A
Low note	1950-55	*69011F	L.H.D., dip right	1951	*A.50869D			
High note	1950-55	*69012F	"	1952-55	50877B			
Alternative	1951-55	*069213	"					

\* See Supersession Chart

L.H. .. Left hand R.H. .. Right hand L.H.D. .. Left hand drive R.H.D. .. Right hand drive

continued

Note. Before ordering Steering Column Controls refer to the detailed parts section (P)









ALLARD 'K3' Model 1954-55—continued

Table with columns: Unit, Year, Part No., Unit, Year, Part No., Unit, Year, Part No. Rows include SWITCHES, Windshield wipers, and various electrical components.

ALLARD 'P' and 'M' Models 1949-51

Table with columns: Unit, Year, Part No., Unit, Year, Part No., Unit, Year, Part No. Rows include Ammeter, Battery, Coil, Ignition, Control box, Distributor, Fuse box, Generator, Horn, LAMPS, SWITCHES, and Windshield wipers.

ALLARD 'P2' Model 1952-55

Table with columns: Unit, Year, Part No., Unit, Year, Part No., Unit, Year, Part No. Rows include Ammeter, Battery, Coil, Ignition, Control box, Distributor, Fuse box, Generator, Horn, LAMPS, SWITCHES, and Windshield wipers.

\* See Supersession Chart L.H. .. Left hand R.H. .. Right hand L.H.D. .. Left hand drive R.H.D. .. Right hand drive

Note. Before ordering Steering Column Controls refer to the detailed parts section (P)



ALLARD 'Clipper' Three-wheeler 1955

Unit	Year	Part No.	Unit	Year	Part No.	Unit	Year	Part No.
Control box .. ..	1955	*37127F	SWITCHES			SWITCHES—continued		
Generator .. ..	1955	22008B	Starting motor .. ..	1955	76423A	Step light .. ..	1955	31082D
Starting motor .. ..	1955	25037A	Coupling .. ..	1955	764428			

ALLARD Palm Beach '21C' and '21Z' Models 1953-55

Unit	Year	Part No.	Unit	Year	Part No.	Unit	Year	Part No.
Ammeter .. ..	1953-55	*36117A	LAMPS—continued			SWITCHES—continued		
Battery .. ..	1953-55	GT9A	Head, Export Europe (not France) .. ..	1955	51339A	Windshield wiper .. ..	1953-55	31201B
Coil ignition .. ..	1953-55	*45012A/D	Head, Export France .. ..	1955	*91590A	Knob .. ..	—	*314691
Control box .. ..	1953-54	*37138B	Number plate illumination .. ..	1953-55	53093E	Terminal block .. ..		
Distributor .. ..	1953	*37139E	Side and flasher .. ..	1953-54	*52051A	" " 21C Model .. ..	1953-55	37101A/B
" 21Z Model .. ..	1953	40252A/B	" " 21Z Model .. ..	1955	52240A	" " 21Z Model .. ..	1955	37101B
" 21C Model .. ..	1953-55	40252D	Stop tail and flasher .. ..	1953-54	53153E	Warning lights		
Flasher unit .. ..	1954-55	*40244A/K	Stop tail and reverse .. ..	1955	53184B	Flasher .. ..	1953-55	*38083A
Fuse box .. ..	1953-55	*35003A	Starting motor .. ..			Ignition .. ..	1953-54	*38013B
Generator .. ..	1953-55	033239	" " 21Z Model .. ..	1953-55	25529A/D	Main beam .. ..	1953-54	38052B
Horn .. ..		22265A/B	" " 21C Model .. ..	1953-55	25022A/L	Petrol .. ..	1953-54	*38042A
Low note .. ..	1953-55	*69011F/J	Steering column control .. ..	1953-55	32892B	Windshield wipers		
High note .. ..	1953-55	*69012F/J	SWITCHES			Motor .. ..	1953-55	75152A
Junction box .. ..	1953-54	78265B	Dipper .. ..	1953-55	31284A	Wheelbox .. ..	1953-55	72629A/D
LAMPS			Ignition .. ..	1953-55	31187D	Crosshead and rack Assy. .. ..		
Head, Home and Export R.H.D., dip left .. ..	1953-54	50941A	Lighting .. ..	1953-55	31126B	Cut to 50 1/2" .. ..	1953-55	736307
ditto .. ..	Later	1954	Knob .. ..	—	*316131	Outer casing .. ..		
ditto .. ..	1955	*51335A	Panel .. ..	1953-55	31201B	Motor to wheelbox .. ..	1953-55	*739832
Head, Export .. ..		51336A	Knob .. ..	—	*314664	Wheelbox to wheelbox .. ..	1953-55	*739971
L.H.D., dip right .. ..	1953-54	50973A	Solenoid, starting motor .. ..	1953-55	*76411D/E	3", offside wheelbox .. ..	1953-55	740031
ditto .. ..	Later	1954	Solenoid operating .. ..	1953-55	*31071A	Arm .. ..	1953-55	*737624
ditto .. ..	1955	*51337B	Stop lamp .. ..	1954-55	31082B	Blade .. ..	1953-55	738724

ALVIS 14 h.p. 1946-50

Unit	Year	Part No.	Unit	Year	Part No.	Unit	Year	Part No.
Ammeter .. ..	1946-50	36023F	LAMPS—continued			SWITCHES—continued		
Battery .. ..	1946-50	SG11A	Side .. ..	1946-50	52030A	Stop lamp .. ..	1946-50	31281B
Coil ignition .. ..	1946-50	*43012A/D	Mirror .. ..	1946-50	*580785	Spring .. ..	—	315543
Control box .. ..	1946-48	*37032A	Petrol reserve valve .. ..	1946-50	78001A	Trafficators .. ..	1946-50	*54039A
Distributor .. ..	1949-50	*37076E	Starting motor .. ..	1946-50	*255721	Warning light (ignition) .. ..	1946-49	*318526
" .. ..	1946-48	40071A/B	Steering column control .. ..	1946	32718A	" " .. ..	1950	318604
" .. ..	1949-50	40071D/F	ditto .. ..	1947-50	32757A	Windshield wipers		
Fuse box .. ..	1946-50	*37137A	ditto (Export) .. ..	1947-50	32755A	Motor .. ..	1946-50	*75053J
Generator .. ..	1946-49	*22447A	ditto (Sports Model) .. ..	1950	32830A	Control box .. ..	1946-50	72561A
Horn .. ..		*22435A/B	SWITCHES			Wheelbox .. ..	1946-50	72560A/K
Low note .. ..	1946-50	*69025A	Heater .. ..	1949	*78220A	Grommet, wheelbox .. ..	1946-50	734697
" (Sports Model) .. ..	1950	*69011F	Knob .. ..	—	*768499	Crosshead and rack Assy. .. ..		
High note .. ..	1946-50	*69026A	Ignition and lighting .. ..	1946-50	*34028B	Cut to 29 1/2" .. ..	1946-50	738764
" (Sports Model) .. ..	1950	*69012F	ditto (Sports Model) .. ..	1950	*34059A	Inner cable rack .. ..	1946-50	736024
LAMPS			Panel .. ..	1946-49	*31063A	Outer casing .. ..		
Head, Home .. ..			Knob .. ..	—	*316205	Motor to wheelbox .. ..	1946-50	*739907
R.H.D., dip left (L.H.) .. ..	1946	50150D	Panel .. ..	1950	*31209A	4", nearside wheelbox .. ..	1946-50	740032
" non dip (R.H.) .. ..	1946	50151D	Knob .. ..	—	*316205	3", offside wheelbox .. ..	1946-50	740031
" dip left (L.H.) .. ..	1949-50	*50330D	Petrol .. ..	1946-49	*31064A	Wheelbox to control box .. ..		
" non-dip (R.H.) .. ..	1949-50	*50331D	Knob .. ..	—	*314662	Offside .. ..	1946-50	739937
Head, Export .. ..			Petrol .. ..	1950	*31209A	Nearside .. ..	1946-50	739937
L.H. .. ..	1949-50	*50580B	Knob .. ..	—	*314662	Guide tube, offside .. ..		
R.H. .. ..	1949-50	*50581B	Reverse lamp .. ..	1946-50	*31077D	wheelbox .. ..	1946-50	735895
Number plate illumination .. ..	1946-50	*53034A	Solenoid, starting motor .. ..	1946-50	76022B	Arm .. ..	1946-50	*73309B
			Solenoid operating .. ..	1946-50	*317089	Blade .. ..	1946-50	727707
						" (Sports Model) .. ..	1950	727784

ALVIS 3 litre TA21 1951-53: TC21, TC21/100, 'Grey Lady' and Tickford Coupé 1954-55

Unit	Year	Part No.	Unit	Year	Part No.	Unit	Year	Part No.
Ammeter .. ..	1951-54	*36111A	LAMPS—continued			SWITCHES—continued		
Battery .. ..	1955	36135A	Head, Export France .. ..	1952-54	*80962A	Petrol reserve .. ..	1951-55	31248A
Coil ignition .. ..	1951-55	GT11A	" .. ..	1955	*51341A	Knob .. ..	—	316367
Control box .. ..	1951-55	*45012A/D	Head, Export U.S.A. .. ..	1951	50811A	Reverse lamp .. ..	1951-55	*31077D
Distributor .. ..	1951-55	*37076E	Number plate illumination .. ..	1951-55	53097D/E	Solenoid, starting motor .. ..	1951-55	*76411D/E
Flasher unit (optional) .. ..	1955	40216A/B	Side .. ..	1951-55	52030A	Solenoid operating .. ..	1951-55	31253A
Flasher relay (when fitted) .. ..	1955	40411A	" (U.S.A.) .. ..	1951-53	52139B	Knob .. ..	—	317362
Fuse box .. ..	1951-55	*35003A	" (Special orders) .. ..	1955	52134B	Stop lamp .. ..	1955	31082D
Generator .. ..	1951-52	33117A	Stop tail .. ..	1951-55	53174B	Windshield wiper .. ..	1951-55	31248A/B
" .. ..	1951-55	37110A	Stop tail and flasher .. ..			Knob .. ..	—	*316369
" .. ..	1951-52	*22435A/B	" (U.S.A.) .. ..	1951-54	53153E	Terminal block .. ..	1951-55	37101A
" .. ..	Later	22456A/B	Mirror (Saloon) .. ..	1951-55	*062553	Trafficators .. ..	1951-53	*54039A
Horn .. ..			" (Coupé) .. ..	1951-55	062573	" .. ..	1954-55	54044D
Low note .. ..	1951-55	*69011F/J	Panel light .. ..	1951-55	39007A	Warning light (ignition) .. ..	1951-54	*38065A
High note .. ..	1951-55	*69012F/J	Bulb .. ..	—	987	" .. ..	1955	38059A
LAMPS			Petrol reserve valve .. ..	1951-53	78020A	Windshield wipers		
Driving .. ..	1954-55	55081A	" .. ..	1953-55	78023A	Motor .. ..	1951-52	*75055L
Fog .. ..	1954-55	*55055A/D	Starting motor .. ..	1951-55	26041A/B	" .. ..	1953-55	75152A
Head, Home and Export R.H.D., dip left .. ..	1951	*50445K	Steering column control .. ..	1951-52	32842F/K	Wheelbox .. ..	1951-55	72560K
ditto .. ..	Later	1951-53	" .. ..	1953-55	32863A/H	Grommet, wheelbox .. ..	1953-55	734181
ditto .. ..	1953	*30954A	SWITCHES			Crosshead and rack Assy. .. ..		
ditto .. ..	1953-55	*51335A	Choke .. ..	1951-55	31248A/B	Cut to 40 1/2" .. ..	1951-55	736307
ditto (alternative) .. ..	1954-55	51336A	Knob .. ..	—	316386	Outer casing .. ..		
Head, Export .. ..		51336A	Dipper .. ..	1951-55	31284A	Motor to wheelbox .. ..	1951-55	739868
L.H.D., dip right .. ..	1951	*A50445K	Foglamp .. ..	1954-55	31201D	Wheelbox to wheelbox .. ..	1951-55	*739966
ditto .. ..	Later	1951-53	Knob .. ..	—	314025	3", offside wheelbox .. ..	1951-55	740031
ditto .. ..	1953	*51338A	Ignition .. ..	1951-55	31187D	Arm, L.H. .. ..	1951-53	*737633
ditto .. ..	1953-54	*51337A	Lighting .. ..	1951-54	*31251A	" R.H. .. ..	1951-53	*737622
ditto .. ..	1955	*51337B	Knob .. ..	—	*316118	L.H. and R.H. .. ..	1953-55	*737596
Head, Export Europe (not France) .. ..	1951	*B50445K	Lighting .. ..	1955	31126B	Blade .. ..	1951-51	727707
ditto .. ..	Later	1951-53	Knob .. ..	—	*316118	" .. ..	Later	737681
ditto .. ..	1954	*30963A	Panel .. ..	1951-55	31248A	" .. ..		
ditto .. ..	1954	*51340A	Knob .. ..	—	*316368			
ditto .. ..	1953-55	51339A						

\* See Supersession Chart L.H. .. Left hand R.H. .. Right hand L.H.D. .. Left hand drive R.H.D. .. Right hand drive

Note. Before ordering Steering Column Controls refer to the detailed parts section (P)